

CC Cream

Phase	I.N.C.I. name	Commercial name	%
A	PEG/PPG-20/15 Dimethicone, Diisopropyl Adipate	Silform™ 60-A (Momentive)	7.00
	Caprylyl Methicone, C30-45 Alkyl Cetearyl Dimethicone Crosspolymer	Velvesil™ 034 (Momentive)	5.00
	Caprylyl Methicone	Silsoft™ 034 (Momentive)	5.00
	Titanium Dioxide, Dimethicone, Hydrogen Dimethicone	SAS-C475001-10 (Miyoshi Europe S.A.S.)	3.60
	Iron Oxides, Dimethicone, Hydrogen Dimethicone	SAS-C339001-10 (Miyoshi Europe S.A.S.)	0.78
	Iron Oxides, Dimethicone, Hydrogen Dimethicone	SAS-C338001-10 (Miyoshi Europe S.A.S.)	0.22
	Iron Oxides, Dimethicone, Hydrogen Dimethicone	SAS-C337001-10 (Miyoshi Europe S.A.S.)	0.13
	Argania Spinosa Oil	Huile d'Argan Biologique (Atelia)	2.00
	C13-15 Alkane	Neossance® Hemisqualane	3.00
B	Nylon-11	Orgasol® Green Touch (Arkema)	2.00
	Polymethylsilsesquioxane	Tospearl™ 150KA (Momentive)	2.00
	PTFE	Microslip® 519L (MPI)	2.00
	Polyethylene, Calcium Silicate, Silica	Microsorb 944S (MPI)	1.50
C	Cyclopentasiloxane, Cyclohexasiloxane, Quaternium-90 Bentonite, Propylene Carbonate	Tixogel® VSP 1438 (BYK)	7.00
	Ethylhexyl Palmitate	Eastman GEM™ 2-Ethylhexyl Palmitate (Eastman)	4.00
D	Dimethicone	Element 14 PDMS 5-A (Momentive)	8.00
	Polymethylsilsesquioxane	Silform™ Flexible Resin (Momentive)	4.00
E	Fragrance	–	0.25
F	Aqua	–	Qs to 100
	Glycerin	–	2.00
	Sodium Chloride	NaCl	1.00
	Aqua	–	2.00
	Cyclodextrin, Sedum Rosea Root Extract	Rhodiola Extract (Sochibios)	0.20
	Butylene Glycol, Aqua, Scutellaria Baicalensis Root Extract	Ougon Liquid B (Ichimaru Pharcos)	2.00
	Glycerin, Aqua, Perfluorodecalin, Simmondsia Chinensis Seed Oil, Sucrose Palmitate, Glycosphingolipids, Xanthan Gum, Sodium Benzoate, Potassium Sorbate	Oxyforce™ (Air Product)	5.00
	Pentylene Glycol	Hydrolite®5 (Symrise)	3.00

Protocol

- Phase DC:** Pre-disperse under stirring the Polymethylsilsesquioxane in the Dimethicone. Do the same operation with Tixogel® VSP 1438 in the Ethylhexyl Palmitate
- Phase A:** Weigh all the ingredients and put them under rotor stator for a few minutes until full dispersion of the pigments.
- Phases ABCDE:** Under stirring, add phase C and D to phase A, then add phase B and finally phase E
- Phase F:** Weigh the deionized water and put under stirring. Add successively the salt, the Glycerin, the Rhodiola Extract (beforehand solubilized in a 2% deionized water solution), the Ougon Liquid B, the Oxyforce™ and finally the Pentylene Glycol
- Under high stirring, add very slowly phase F to phase ABCDE